

REPEATABLE DATA ENTRY WITH EID, NO WEIGHING OR DRAFTING

These instructions describe how to set up the indicator for recording data against large numbers of animals (like sheep) that all have the same data. e.g. sex or source.

STEP 1:

If required, set up a field for data entry in the Life Data or File Data screens.

To set up a data field, press **LIFEDATA** or **FILEDATA**.

Set up field options, as required.

For more information about setting up data fields, see the XR3000 User Manual.

In this example, a life data field has been set up to record the animal's sex.

Note: Repeat is ticked for Sex.

Custom type is an option here, see user manual or Indicator Help for set up.

Life Data Setup						
AUTO INC. FIELD : Off				PREFIX FIELD : Off		
LABEL	ON/OFF	TYPE	ID	FORMAT OR LENGTH	REPEAT	
FID	✓	Text	✓	14		✗
EID	✓	Text	✓	16		✗
LID	✗	Text	✓	16		✗
Mob	✗	Text	✗	4		✗
Class	✗	Text	✗	4		✗
Breed	✗	Custom	✗			✗
DOB	✗	Date	✗	dd/mm/yyyy		✗
SEX	✓	Text	✗	4		✓

CUSTOM

STEP 2:

Press and set up the screen as shown:

Note: Sex is ticked so it will appear as a data entry field on the right hand side of the Weighing screen.

Weighing Screen Setup FILE: 25	
Tick the items you want on the main weighing screen.	
LHS (FOR VIEWING)	RHS (FOR DATA ENTRY)
✓ Prompt message	✗ FID
✗ Draft range	✓ EID
✗ Carcass weight	✗ LID
✗ Value	• Mob
✗ Weight gain	• Class
✗ Prediction	• Breed
✗ Days	• DOB
---	✓ SEX
---	---
✗ FID	---
▼ ✗ EID	---
	✗ Code1

LIFEDATA FILEDATA DRAFT W.GAIN SYSTEM ►

STEP 3:

To select a file, press **FILES** then scroll to the new file.

Note: It is good practice to start a new file each time a new session is started. You should name the file relevant to the job you are doing. This is good practice for record keeping.

List of Files			
FILE	FILE NAME	RECORDS	START DATE
12		0	
13	LAMBS SEXING 09	0	
14		0	
15		0	
16		0	
17		0	
18		0	
19		0	
20		0	
21		0	
▼ 22		0	

TOP BOTTOM SORT FIND FILEDATA ►

REPEATABLE DATA ENTRY WITH EID, NO WEIGHING OR DRAFTING

STEP 4:

Optimise the system for the task being performed.

Press  **SYSTEM**.

As animals are not being weighed, set Weight Recording to **Off** in order to increase the speed of data entry.

Tick ID Entry Creates File Rec to allow the XR3000 to record data without weighing.

System Setup	
DAMP SYSTEM:	Superdamp III (Cattle)
WEIGHT RECORDING:	Off
RESOLUTION:	0.5
SET TARE:	0.0 kg
AUTO ZERO TRACK:	On Net
POWER UP ZERO:	<input checked="" type="checkbox"/>
AUTO POWER OFF:	<input checked="" type="checkbox"/>
REWEIGH SOFTKEY:	<input checked="" type="checkbox"/>
REVERSE WEIGHING:	<input checked="" type="checkbox"/>
COUNTRY:	AU
DATE:	19/03/2010
TIME:	11:04
FONT:	Original
BACKLIGHT:	On
CONTRAST:	5
STARTUP SCREEN:	<input checked="" type="checkbox"/>
ID ENTRY CREATES FILE REC.:	<input checked="" type="checkbox"/>
DISABLE POPUPS:	<input checked="" type="checkbox"/>
SOUND:	Standard

STEP 5:

Set up the EID device.

Ensure the EID reader is plugged into CON 2.

Press   **SERIAL**.

Set up the screen as shown:

Serial Setup	
PRINTER OUTPUT:	CON1 RS232 Xon/Xoff 9600 bps
PRINT REPORT HEADING:	
PRINTER TYPE:	40 column
SERIAL OUTPUT:	<input checked="" type="checkbox"/>
CON 1 INPUT:	<input checked="" type="checkbox"/>
CON 2 INPUT:	<input checked="" type="checkbox"/> EID
CON 2 MIN CHARS:	15
RS232	9600 bps
SCP ADDRESS:	20
B.TOOTHH	

STEP 6:

The main screen should be displayed as shown:

Note: When the data is entered for sex the field will remain and repeat for each animal. If this is changed during weighing it will continue to repeat with the new value.



Need more help?

For further information regarding your stock management system contact Tru-Test on 1800 641 324 (AU) or 0800 878 837 (NZ)